

Tyre Pressure Gauge


TYG**NEW!**

Compact pocket size air pressure gauge


Pressure range from 10-50 PSI

Metallic wear & tear resistant body

Accuracy ± 1 PSI



Mate the mouth of the tyre pressure gauge with the air valve of the tyre



Press the tyre pressure gauge on the valve



Check the reading on the pressure reading tube that slides out of the tyre pressure gauge



ORDERING INFORMATION

CAT NR.	ORD NR.	BOX QTY.
TYG/10-50/GRZ	61396	25