




INSTRUCTION MANUAL

S3900, REV B

## Underhood Light High Intensity – Glare Free

LED-353



World's First 5000 Lumen Underhood Light

Flicker-free and glare-free light ensures constant work output

### Multi-mode output

Multiple mode output ensures user comfort

	1ST PRESS	2ND PRESS	3RD PRESS
HIGH INTENSITY			
LUMEN	5000	2500	1000
RUN TIME	3 hrs	6 hrs	15 hrs

### Sturdy Construction

- Aluminium extruded body
- Strong steel hooks with non-marring rubber coating
- Hooks can be conveniently rotated for firm grip

### Expandable Length


Expandable length 1.2m–1.72m (46-1/2"–68") provides maximum utility for under-hood, undercarriage or over-dash applications

### Charging of Battery

Battery can be recharged using in-built Type C charging port

Complete with 9' long cable for uninterrupted charging even when light is in use & AC power adaptor

CAT NR.	SIZE	
	(INCH)	(MM)
LED/353	46-1/2 x 2 x 3	1188 x 50 x 75



### POWER SOURCE




7.4V 5000 mAh



## PACKAGING CONTENT

DESCRIPTION	QUANTITY
Light	1
USB cable	1
Adaptor	1

## NOMENCLATURE



1. Hooks for mounting
2. Glare-Free SMD LEDs
3. Battery indicator LEDs
4. Charging port Type C
5. ON/OFF Button

## SAFETY INFORMATION

- Keep the work area clean and dry. Damp or wet work areas can result in injury.
- Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged parts immediately.
- Do not use the lamp in the immediate vicinity of inflammable materials or gases.
- Only use the accessories included with the product.
- Keep the lamp out of reach of unauthorized persons, especially children.
- Do not point the light directly in your own or any other person's or animal's eyes.
- Do not attempt to open the battery compartment.

## OPERATING INSTRUCTIONS

(Refer "NOMENCLATURE")

### Charging:

- Connect the Type C end of the charging cable to the charging port on the work light.
- Insert the USB end of the cable into the USB port on the wall charger.
- Plug the AC charger into a live AC outlet. The green LEDs will light, to indicate battery status.
- Charging will take 8 hours. When the battery is fully charged, all four LEDs will be lit.
- Now the light is ready for use.
- Fully charge the battery before the first use.

### Operation:

- To switch ON the light press the button at the side of the unit.
- Press the button once for 5000 lumens light
- Press the button twice for 2500 lumens light
- Press the button thrice for 1000 lumens light
- Press the button four times to switch off the lights.

## MAINTENANCE

- Before cleaning the LED work light, disconnect the Type C cable (if being charged) and allow the work light to cool down sufficiently.
- Clean with a dry or slightly moist, clean, lint free cloth and a mild detergent if required.
- Do not use cleaners that contain abrasives or solvents.
- Check the LED work light for damage before each use. If the lens is damaged it must be replaced immediately.
- Clean any dirt from the housing or the lens immediately, since it could cause overheating.

## INSTRUCTIONS FOR PROPER USE OF UNDERHOOD LIGHT

- Make sure that the light does not fall from a height as it can damage the bracket and housing of the light



- Light should not be bent in any direction as it puts pressure onto the hooks and it can get damaged



- Avoid putting any horizontal force onto the light as it can damage the light



- While removing the light from the vehicle, hold the light firmly and ensure that the light is retracted slowly to avoid excessive force on the hook and prevent its damage



- Do not pull the light with any excessive force as it can damage the light

## DISPOSAL

The components or the used products must be given to companies that specialize in the disposal and recycling of industrial waste.



## NOTE



---

**Groz Engineering Tools Pvt. Ltd.  
Groz Net Industries**

Village Kherki Daula, National Highway-8,  
Gurugram-122004, Haryana, INDIA

**Tel** +91.124.282.7700  
**E-Mail** [info@groz-tools.com](mailto:info@groz-tools.com)  
**Url** [www.groz-tools.com](http://www.groz-tools.com)

The GROZ name, GROZ logo and the  mark are trademarks of GROZ Engineering Tools Pvt. Ltd., India