

### Worklight Cable Reel

LED-800



4000

**4000 lumens worklight with built-in cable reel**

#### Sturdy Construction

- IP 54 Rated**  
Protected against dust and effects of water spray from any direction
- IK 07 Rated**  
Impact-proof aluminium die cast housing with polycarbonate lens will stand-up to tough jobsite conditions
- In-built handle for comfortable grip
- Complete with 5m (16ft) cable with a socket useful to connect multiple lights in series for higher illumination

#### Versatile Use

- Free standing worklight with adjustable swivel stand
- Attached to any metallic surface using 4 super strong magnets at the back of light



Swivel stand

#### POWER SOURCE



AC

220V AC, 50Hz  
110 V AC, 60Hz



90° rotating COB light to focus beam as needed



4 Super strong magnets on the back



3000W Socket on one end, to connect multiple lights in series or use the socket to connect to a power tool

| CAT NR.    | PLUG TYPE | POWER SOURCE  |
|------------|-----------|---------------|
| LED/800/EU | EU        | 220V AC, 50Hz |
| LED/800/US | US        | 110V AC, 60Hz |



SCAN TO WATCH



Dia.  
12-1/64"  
(305 mm)

CE  
RoHS  
IP54  
IK07



## SAFETY INFORMATION

- Follow workshop health & safety rules, regulations and conditions when using worklight.
- When not in use, worklight should be stored in a dry location to inhibit rust.
- During their period of use, accessories must be checked for wear, cracks and other damage, replace any damaged or worn parts.
- Use genuine parts only. Unauthorized parts may be dangerous and will void the warranty.
- Keep the worklight clean and in good working order for best and safest performance.
- DO NOT use the lamp in the immediate vicinity of inflammable materials or gases.
- DO NOT point the light directly in your own or any other person's or animal's eyes.
- DO NOT drop, throw or abuse the worklight.
- Eyes protection:** Wear a protective mask or protective eyewear.
- Check that the product has not suffered any damage during transport or storage. Clean and remove any dust or residual packing material.
- Read the instructions carefully before using worklight and keep them for further reference.

## WARNING!

- DO NOT immerse worklight in water.
- DO NOT place worklight near a fire or any other source of intense heat.
- DO NOT attempt to open, disassemble, modify or service the worklight.
- DO NOT expose worklight to temperatures above 50°C (122° F).
- DO NOT use worklight if you suspect that the casing is damaged
- DO NOT exceed the total load above 3000W.

## PACKAGING CONTENT

| DESCRIPTION | QTY. |
|-------------|------|
| Worklight   | 1    |
| O.I.P.M.    | 1    |

## OPERATING INSTRUCTION

- To use the worklight, plug in the worklight to an AC power source.
- Switch ON / OFF the worklight using the switch provided on the front of the worklight.
- To use the worklight in series, make sure that all the lights are disconnected from the AC power source to avoid any accidents.
- Open the protective cap of the socket of the first worklight and insert the plug of the second worklight in it. Similarly, more lights can be connected in series.
- Connect the plug of the first worklight in an AC power source and switch ON the power source.
- Ensure that the combined load of all the devices connected in series is within the 3000W limit

## MAINTENANCE

- Clean any dirt from the housing or the lens immediately, since it could cause overheating.
- If required, clean with a dry or slightly moist clean cloth. Do not use cleaners that contain abrasives or solvents.
- When not in use, worklight should be stored in a dry location.

## TROUBLESHOOTING

| PROBLEM                             | POSSIBLE CAUSE                               | CORRECTIVE ACTION                                  |
|-------------------------------------|--|--|
| If the worklight doesn't work       | Loose connection or power source not working | Check for loose connections and check power source |
| If the worklight still doesn't work |  | Contact nearest authorized service dealer          |

## DISPOSAL

The components or the used products must be given to companies that specialize in the disposal and recycling of industrial waste.

## Groz Engineering Tools Pvt. Ltd. Groz Net Industries

Village Kherki Daula, National Highway-8,  
Gurugram-122001, Haryana, INDIA

**Tel** +91.124.282.7700

**E-Mail** info@groz-tools.com

**Url** www.groz-tools.com

The GROZ name, GROZ logo and the  mark are trademarks of GROZ Engineering Tools Pvt. Ltd., India